

UFH Electric Boiler - Smart Plus Integration

Please follow these Instructions on how to convert the Electric boiler to work with the Smart Plus controls rather than the supplied RF programmable thermostat (UFHPROGB)

Replace the programmable room thermostat (UFHPROGB) and receiver (PBRECRF) with the Central Radiator Controller (UFHINTRADP) and a single room sensor (e.g. UFHSENSEWP or UFHCMINIP).

Remove the PBRECRF and take the switch wires from this to the vault free relay in the UFHINTRADP, this has its own power supply (3 pin plug). Pair the stat to UFHINTRADP and register this to the emodul account - (<https://polypipe.emodul.eu/login>). To pair the temperature sensor to the UFHINTRADP Programming is done through the emodul app or website.

